


# AQUEOUS DPF CLEANING

## BEST FOR:



ALL DPF  
SHAPES



TIME-SENSITIVE  
CLEANING

## STAGE 1: PRE-CLEAN

### INSPECT & BENCHMARK

- Visual inspection
- Wire/pin test for plugged cells
- Measure the airflow
- Check for cracks in the brick using the built-in light
- Record pre-cleaning weight



### DOCUMENT

- Record pre-clean benchmark results
- Take “before” pictures of filter
- 1-year subscription to FilterTrak included with equipment



## STAGE 2: CLEAN



### PRE-SOAK

- Pre-soak the filter for 10 minutes with surfactant.

### WASH

- Run the Wash cycle
- Takes about 20 minutes



### DRY

- Most filters dry in 20 minutes

## STAGE 3: POST-CLEAN

### INSPECT & BENCHMARK

- Measure the airflow
- Wire/pin test
- Record post-cleaning weight



### DOCUMENT

- Record post-clean benchmark results
- Take “after” pictures of filter



### FINISH

- Re-install the clean filter on the vehicle



**FILTERTHERM**<sup>®</sup>